


ADQ7 Datasheet



ADQ7 is a high-end 14b data acquisition platform, designed to meet the most challenging measurement situations. ADQ7 features:

- 1 and 2 channels operations*
- 10 GSPS, or 5 GSPS per channel*
- 5 GByte/s sustained data transfer rate*
- Open FPGA for real-time DSP*
- Pulse detection firmware option*
- Software defined radio firmware option*



Copyright CERN

ADQ7 Datasheet

Features

- 1 or 2 analog channels
- 5 to 10 GSPS sample rate per channel
- 14 bits vertical resolution
- DC-coupled with up to 2.5 GHz analog BW optimized for low noise.
- AC-coupled with up to 2.5 GHz analog BW optimized for wide band linearity
- Programmable DC-offset
- Internal and external clock reference
- Internal and external clock
- Clock reference output
- Internal and external trigger
- Multi-unit synchronization
- Time-stamp for real-time operation
- 4 GBytes data memory
- 5 GBytes/s sustained data streaming
- Data interface
PCIe / PXIe / USB3.0 / MTCA.4 / 10 GbE

ADQ7 Development Kit

- Open FPGA for custom applications
- Real-time signal processing

Applications

- RADAR
- LIDAR
- Wireless communication
- L-band direct sampling
- High-speed RF data recording
- Time-of-flight
- Scientific instruments
- Particle physics
- Semiconductor test
- ATE
- Test and measurement
- Quantum technology

Advantages

- PC interface options for optimized systems partitioning.
- Advanced analog front-end and high sample rate for meeting detector and measurement requirements.
- Real-time custom processing for partitioning of advanced systems. This optimizes cost of ownership.
- SP Devices' design services are available for fast integration to lower time-to-market.

Flexible high performance digitizer solution

The ADQ7 is available in many different configurations to suit a very wide variety of measurement challenges.


The DC-coupled front-end is optimized for pulse data applications and for zero-IF RF applications while the AC-coupled front-end is ideal for non-zero IF-sampling and direct sampling RF applications.

Several firmware options are offered, providing a comprehensive range of general and application specific features to reduce TTM and off-load the host computer. Custom FPGA firmware is enabled

through the open architecture for maximum flexibility and performance.

The different host interfaces/form factor options allow the ADQ7 to be integrated into a wide range of system architectures. The form factor sets the communication interface to the host PC as well as the mechanical properties of the ADQ7.

The ADQ7 comes with a software development kit to facilitate the implementation of the user's application. ADQ7 supports Windows and the main Linux distributions.



1 Selection guide

There are several options for ADQ7. Follow the steps below to determine which kind of ADQ7 best suits your application. **Table 1** describes which combinations of options that are available. Each of the items below are further described in detail in the following sections of this document.

1. Select AC- or DC-coupled front-end. This will determine the model ADQ7AC or ADQ7DC.
2. Select form factor; –USB, –PCIE, –PXIE or –MTCA.
3. Select one or several of the firmware packages; –FWDAQ, –FWPD, –FWATD or/and –FWSDR.
4. Add ADQ7 Development Kit if custom real-time signal processing in the FPGA is required; –DEV7DAQ or/and –DEV7PD.

Table 1: Selection guide

		ADQ7AC	ADQ7DC
Key parameters			
Number of channels ¹		2	2 / 1
Sample rate / channel ²	[GSPS]	5	5 / 10
Analog front-end			
AC-Coupling		✓	
DC-Coupling			✓
50 Ω input impedance		✓	✓
Variable DC-offset			✓
Over-voltage protection			✓
Anti-aliasing filter			✓
Synchronization			
External clock reference		✓	✓
External trigger in/out		✓	✓
Synchronization in/out		✓	✓
Mechanical form factor (select one)			
Stand-alone box (USB3.0, 10GbE, 1GbE ³)	–USB		✓
PXIE Gen3 x8	–PXIE	✓	✓
PCIE Gen3 x8	–PCIE	✓	✓
MTCA.4 (Gen3x4, USB3.0, 10GbE, 1GbE ³)	–MTCA		✓
Firmware			
Data Acquisition (included)	–FWDAQ	✓	✓
Dynamic Pulse Data	–FWPD		✓
Advanced time domain averaging	–FWATD		✓
Radio Systems	–FWSDR	✓	✓ ⁴
ADQ7 Development Kit for –FWDAQ	–DEV7DAQ	✓	✓
ADQ7 Development Kit for –FWPD ⁵	–DEV7PD		✓

1. Software selectable number of channels
2. Sample rate with internal clock source. Use external clock for other frequencies.
3. The 1 GbE port is intended for White Rabbit timing solutions.
4. –PXIE and –PCIE interfaces only
5. Requires a license for –FWPD

2 Preliminary technical data¹

Table 2: General parameters

PARAMETER		ADQ7AC	ADQ7DC
Key parameters			
Channels ¹		2	2 / 1
Sample rate / channel	[GSPS]	5	5 / 10
Resolution	[bits]	14	14
Data memory ²	[GByte]	4	4
Power			
Power supply	[V]	12	12
Power dissipation	[W]	50	60

1. Software selectable number of channels
2. The data memory is shared between data (2 bytes per sample) and record headers.

Table 3: Analog input

		ADQ7AC	ADQ7DC
Analog inputs			
Coupling		AC	DC
Input Impedance AC	[Ω]	50	50
Input Impedance DC	[Ω]	100k	50
Input range 1 channels mode	[V _{pp}]	–	1
Input range 2 channels mode	[V _{pp}]	1	1
Over-voltage protection		See Table 13	See Table 13
Bandwidth lower –3 dB	[MHz]	100	DC
Bandwidth upper –1 dB	[GHz]	TBD	TBD
Bandwidth upper –3 dB	[GHz]	2.5	2.5 ¹
Connector		SMA	SMA
Variable DC-offset			
Variable DC-offset range, 1 channel	[V]	–	± 0.5
Variable DC-offset range, 2 channels	[V]	–	±0.5

1. Upper bandwidth limit is 3 GHz with digital equalizer.

1. All values are typical unless otherwise noted.

Table 4: Dynamic performance (TBD)

		ADQ7AC	ADQ7DC
Analog performance up to 1 GHz			
SNR	[dB]	56	56
SNDR	[dB]	56	56
SFDR [dBc]		65	60
ENOB	[bits]	9	9
Analog performance up to 2.5 GHz			
SNR	[dB]		56
SNDR	[dB]		46
SFDR	[dBc]	60	46
ENOB	[bits]	9	7.3

Table 5: Clock

		ADQ7AC	ADQ7DC
Internal Clock Reference			
Frequency	[MHz]	10	10
Accuracy	[ppm]	$\pm 3 \pm 1/\text{year}$	$\pm 3 \pm 1/\text{year}$
External clock reference input			
Frequency	[MHz]	10/100 MHz ± 5 ppm	10/100 MHz ± 5 ppm
Signal level (min – max)	[Vpp]	0.5 – 3.3	0.5 – 3.3
Impedance AC	[Ω]	50	50
Impedance AC (high ¹)	[Ω]	200	200
Impedance DC	[Ω]	10 k	10 k
Duty cycle		TBD	TBD
Connector		SMA	SMA
MTCA.4 clock reference²			
TCLKA	[MHz]	–	10
TCLKB	[MHz]	–	10
Clock reference output			
Frequency	[MHz]	10	10
Signal level into 50 Ω load	[Vpp]	1.2	1.2
Output impedance AC	[Ω]	50	50
Output impedance DC	[Ω]	10 k	10 k
Duty cycle		50% $\pm 5\%$	50% $\pm 5\%$
Connector		SMA	SMA
External clock input³			
Frequency	[GHz]	TBD	TBD

1. Software-controlled high-impedance setting for large fan-out distribution using bussed connection.
2. Available on ADQ7 with option –MTCA.
3. Sample rate in 1 channels mode is 4 x external clock frequency. Sample rate in 2 channels mode is 2 x external clock frequency.

Table 6: Trigger/GPIO input/output connector

		ADQ7AC	ADQ7DC
Connector			
Connector shared between input and output		SMA	SMA
Input mode			
PRF (max)	[MHz]	78.125	78.125
Impedance DC	[Ω]	50	50
Impedance DC (high ¹)	[Ω]	>500	>500
Signal level (min – max)	[V]	–0.5 to 3.3	–0.5 to 3.3
Adjustable trigger threshold ²	[V]	0 to 3	0 to 3
Time resolution	[ps]	25	25
Excess jitter ³	[ps]	25	25
Max GPIO data rate	[Mbit/s]	156.25	156.25
Output mode			
PRF (max)	[MHz]	100	100
Signal level output low max	[V]	0.1	0.1
Signal level output high min	[V]	2.2 (into 50 Ω load)	2.2 (into 50 Ω load)
Impedance DC	[Ω]	50	50
GPIO data rate	[Mbit/s]	156.25	156.25

1. Software-controlled high-impedance setting for large fan-out distribution using bussed connection.
2. Set threshold to match desired electrical standard when used as GPIO input.
3. The excess jitter is jitter added to the trigger signal in addition to the jitter caused by the finite timing resolution.

Table 7: Sync/GPIO input/output connector

		ADQ7AC	ADQ7DC
Connector			
Connector shared between input and output		SMA	SMA
External sync input			
PRF (max)	[MHz]	78.125	78.125
Impedance DC	[Ω]	50	50
Impedance DC (high ¹)	[Ω]	>500	>500
Signal level (min – max)	[V]	–0.5 to 3.3	–0.5 to 3.3
Adjustable trigger threshold ²	[V]	0 to 3	0 to 3
Max GPIO data rate	[Mbit/s]	156.25	156.25
Sync output			
PRF (max)	[MHz]	>1	>1
Signal level output low max	[V]	0.1	0.1
Signal level output high min	[V]	2.2 (into 50 Ω load)	2.2 (into 50 Ω load)
Output impedance DC	[Ω]	50	50
GPIO data rate	[Mbit/s]	156.25	156.25

1. Software-controlled high-impedance setting for large fan-out distribution using bussed connection.
2. Set threshold to match desired electrical standard when used as GPIO input.

Table 8: GPIO option

MODEL OPTION	ADQ7AC AND ADQ7DC			
	-USB	-PXIE	-PCIE	-MTCA
GPIO				
Number of GPIO signals ¹	TBD	TBD	TBD	TBD

1. GPIO option in addition to trigger and sync used as GPIO.

Table 9: General specifications

INTERFACE TO HOST PC	OPTION	-USB		-PXIE	-PCIE	-MTCA
		USB3.0	10 GBE	PCIE	PCIE	PCIE
Data rate						
Standard		USB3.0	UDP point to point	Gen3 by 8 lanes	Gen3 by 8 lanes	Gen3 by 4 lanes
Data rate peak ¹	[MBytes/s]	400	1250	6800	6800	3400
Data rate sustained ²	[MBytes/s]	200	1000	5000	5000	2500
Mechanical						
Box size	[mm ³]	208,3 x 217,6 x 53		–	–	–
Bus width mechanical	[lanes]	–		–	16 ³	8
Weight	[g]	1000		700	700	800
Board width	[slot]	–		2	2	Double width
Board length		–		–	full length	–
Board height		–		3U	–	Mid-size
Electrical						
Power supply		External ⁴		From chassis	6-pin ATX power	From chassis
Bus width electrical	[lanes]	–		8	8	4
Temperature range						
Operation	[°C]	0 to 45		0 to 45	0 to 45	0 to 45
Compliances						
CE		✓		✓	✓	✓
RoHS2		✓		✓	✓	✓
FCC		Exclusion according to CFR 47, part 15, paragraph 15.103(c)				

1. This is the peak capacity supported by ADQ7. The system performance is depends on the capacity of the complete system, including the host computer.
2. This is the sustained data rate supported by ADQ7, i.e. the transfer rate of data (excluding headers etc.) maintained on average for a long time. The system performance is depends on the capacity of the complete system, including the host computer.
3. The wide contact is required to support the weight of the board.
4. Use only the power supply which is included in the delivery of ADQ7-USB.

Table 10: Firmware option feature list

MODEL OPTION	ADQ7AC AND ADQ7DC			
	-FWDAQ	-FWATD	-FWPD	-FWSDR
Signal enhancement IP				
DBS	✓	✓	✓	
ADX				✓
Trigger modes				
Software trigger	✓	✓		✓
External trigger	✓	✓	✓	✓
Common level trigger ¹	✓	✓		
Individual level trigger ²			✓	
PXle backplane trigger ³	✓			✓
MTCA backplane trigger ⁴	✓		✓	
Internal trigger	✓	✓		✓
Trigger output				
Internal trigger	✓	✓	✓	✓
Trigger event	✓	✓	✓	✓
Clock				
Internal clock reference	✓	✓	✓	✓
External clock reference	✓	✓	✓	✓
Sample skip	✓	✓		✓
Data acquisition modes				
Continuous streaming	✓			✓
Triggered streaming with header	✓	✓	✓	✓
Triggered streaming w/o header	✓			✓
Dynamic record length			✓	

1. Both channels trigger simultaneously at an event on one selected channel.
2. Each channel triggers independently of the other.
3. Requires system timing module.
4. Port 17 is activated. Other ports requires custom firmware.

Table 11: Data acquisition parameters

MODEL SETTING	ADQ7AC	ADQ7DC	
	2 CHANNELS	1 CHANNEL	2 CHANNELS
Triggered streaming			
Re-arm time [ns]	20	20	20
Pre-trigger length [samples]	8 ki	16 ki	8 ki
Pre-trigger length resolution [samples]	4	8	4
Trigger delay [samples]	$2^{31} - 1$	$2^{32} - 1$	$2^{31} - 1$
Trigger delay length resolution [samples]	4	8	4
Record length max [samples]	1 Gi	2 Gi	1 Gi
Record length min [samples]	20	40	20
Record length resolution [samples]	4	8	4
Continuous streaming			
Data rate	PC link speed limit, see Table 9		

Table 12: Software support

	ADQ7AC	ADQ7DC
Operating systems		
Windows 7 32b and 64b		✓
Windows 8 / 8.1		✓
Windows 10		✓
Linux ¹	Kernel 2 and 3, main distributions	
Application		
GUI	ADCaptureLab ² for –FWDAQ Python GUI for –FWPD and –FWATD	
MATLAB ³	API, examples	
C/C++	API, examples	
.Net (C#, Visual Basic)	API, examples	
Python	Example scripts	
LabVIEW	DLL import	

1. Contact an SP Devices sales representative for information about currently supported distributions.
2. Windows only
3. Windows only

3 Absolute maximum ratings

Exposure to conditions exceeding these ratings may reduce lifetime or permanently damage the device. The analog inputs are protected from over-voltage but the values in [Table 13](#) must never be exceeded.

The ADQ7–USB and ADQ7–PCIE has a built-in fan to cool the device. ADQ7–MTCA is cooled from the chassis fan. The built-in temperature monitoring unit will protect the ADQ7 from overheating by temporarily shutting down parts of the device in an overheat situation.

The SMA connectors have an expected life time of 100 operations. For frequent connecting and disconnecting of cables, connector savers are required.

Table 13: Absolute Maximum Ratings

		ADQ7AC	ADQ7DC
Analog input			
AC f >10 MHz	[Vpp]	TBD	TBD
AC f <10 MHz	[Vpp]	TBD	TBD
DC max ¹	[V]	TBD	–2
DC min ¹	[V]	TBD	+2
External clock reference			
Signal level AC ¹	[Vpp]	5	5
Signal level DC ¹	[V]	± 5	± 5
External trigger input			
Signal level to GND min	[V]	–2	–2
Signal level to GND max 50-ohm mode	[V]	4.5	4.5
Signal level to GND max high impedance mode	[V]	5.5	5.5
External sync input			
Signal level to GND min	[V]	–2	–2
Signal level to GND max 50-ohm mode	[V]	4.5	4.5
Signal level to GND max high impedance mode	[V]	5.5	5.5
Power supply			
Voltage to GND (min)	[V]	–0.4	–0.4
Voltage to GND (max)	[V]	14	14
Temperature			
Operating (min)	[°C]	0	0
Operating (max)	[°C]	45	45

1. The instantaneous voltage must never exceed the DC level limits.

4 Integrating the ADQ7

Figure 1 illustrates how ADQ7 supports the key parts of the system integration.

4.1 Detecting the analog signal

The analog front-end combines high dynamic range with high bandwidth to support the most advanced detectors. The DC-coupled front-end has high sensitivity to simplify the interfacing. DC-offset enable doubled resolution for uni-polar pulses. The AC-coupled front-end is optimized for linearity at high frequencies, which is required for RF applications.

4.2 Timing and synchronization

The clock management and trigger support connects with the infrastructure of the system. There are two main situations where synchronization is required; one ADQ7 to another type of equipment and several ADQ7 units in a multi-channel application.

The ADQ7 can act as master and generate timing for the entire system and thereby save additional timing cards. It can also receive trigger and clocks from other devices. Synchronization and GPIO signals allow advanced sequencing.

The methods for synchronize several units in one location according to the application note 15-1583 “ADQ14 synchronizing several units” are also valid for ADQ7. For an installation with long distance between the measurement nodes, White Rabbit enables accurate timing.

4.3 Real-time signal processing

The data acquisition engine in the FPGA supports several methods for acquiring data and transfer it to the host PC. Since the data rate from the ADC

is high, some parts of the application is preferably integrated into the FPGA to relax the load on the CPU in the host computer. There is a set of application-specific firmware options available to enable efficient real-time signal processing. In addition, the FPGA is open to the user through the ADQ7 Development Kit for integration of custom algorithms.

4.4 System integration

The interface to the host PC is one important parameter in the system integration. To enable an optimal solution, the ADQ7 offers a wide variety of form factors.

Both the mechanical and electrical properties in various standards are important for the result. The mechanical properties enables an optimal placement of the ADQ7 inside the target system and also which type of PC to use. The different electrical properties of the interface determine data transfer rate and noise immunity.

4.5 Building the application

The open ADQAPI is a software package including drivers and software development kit for integrating the ADQ7 into an application. The many examples and application notes simplify the integration process and shorten the time-to-market.

Partitioning the application between a high level analysis software in the host PC and a low level real-time data analysis in the open FPGA enables high performance applications to run on a cost-effective PC solution.




Figure 1: Integrating the ADQ7 into the system.

5 Software tools

5.1 Operating systems

The software package includes drivers for the most common versions of Windows and several Linux distributions.

5.2 Software development kit, SDK

The ADQ7 digitizer is easily integrated into the application by using the software development kit, SDK. The SDK is included free of charge with the ADQ7.

The SDK includes programming examples and reference projects for several platforms. The ADQAPI reference guide describes all functions in detail.

Using the SDK enables rapid custom processing of large amounts of data and real-time control of the digitizer.

5.3 ADCaptureLab GUI

The ADQ7 is supplied with the ADCaptureLab software that provides quick and easy control of the digitizer. The tool also offers both time-domain and frequency-domain analysis, see **Figure 2**. Data can be saved in different file formats for off-line analysis. With ADCaptureLab, the ADQ7 operates as a bench-top oscilloscope.

Note that the GUI ADCaptureLab only represent a subset of the flexibility of the ADQ7. The full potential of the ADQ7 is reached using the SDK.

ADCaptureLab is available for Windows only.




Figure 2: ADCaptureLab.

6 Block diagram

The ADQ7 can be configured in many ways. A detailed block diagram for one of the available configurations is shown in **Figure 3**. The following sections describe the parts of the ADQ7 in detail. Also see the 16-1787 ADQ7 Manual for more details on how to operate the ADQ7.

This datasheet describes functions included in the standard data acquisition firmware package –FWDAQ. When functions from optional application specific firmware packages are described, there references to the respective option. The optional firmware packages are further described in their respective datasheets.





Figure 3: Block diagram for ADQ7DC (dual/single-channel, DC-coupled).

7 Analog front-end options

AC-coupling (ADQ7AC)




The AC-coupled analog front-end has the best linearity performance at high frequency.

The input is AC-coupled and AC-terminated to 50 ohms.

The ADQ7AC is always configured with 2 inputs.

DC-coupling (ADQ7DC)




The DC-coupled analog front-end contains overvoltage protection and software programmable DC-offset. The DC-coupled AFE also has a noise-suppression anti-aliasing filter. The DC-offset is set in 15 steps and the range is covering the full signal range. The settings are user controlled via software.

The overvoltage protection is crucial in pulse data systems where high voltage detectors are driving the input. The overvoltage protection reduces the damage at accidental discharges. See [Section 3](#) for absolute limits without damage.

The DC-coupled front-end is switchable between 2 channels and one channel with time interleaved sampling, which result in twice the sample rate.


Number of channels



The ADQ7AC is available with 2 channels operating at 5 GSPS each.

The ADQ7DC is dynamically switchable between two channels at 5 GSPS and one channel at 10 GSPS.

8 Data recording




Triggered streaming

Use triggered streaming for maximum throughput.

At each trigger, a record (set of continuous data) is captured. The record is buffered in the DRAM, which acts as a FIFO, and transferred to the host PC. This large 4 GBytes FIFO enables bursts of triggers at a very high rate. The large FIFO also guarantees reliable high speed transfer to the PC.


Each record has a header with time-stamp and identifiers for post-processing analysis of the data.



Continuous streaming

This mode is for continuous recording of very long events.

The recording starts at a trigger event and continues until it is terminated by the user. The continuous streaming mode produces a large amount of data and is often combined with a data reduction method in the FPGA. This could be, for example, channel masking, DDC and decimation (option –FWSDR), sample skip, or a custom algorithm implemented using the ADQ7 Development Kit



Data FIFO

Guarantees reliable data transfer.

There is 4 GBytes of on-board DRAM which is typically used as a large FIFO. The FIFO guarantees stable operation over a long time at high data rates. The large FIFO also enables bursts of triggers at high rate.


Data transfer

Optimized for high throughput.

ADQ7 supports several electrical/mechanical interfaces to meet specific systems design requirements. The software methods for data transfer are unified to work the same for all formats. The API supports efficient multi-threaded handling of data buffers. There is example code for fast integration into the application.

Note that the multi-threading is for handling the data buffers only. The ADQ7 set up and control has to be a single thread.


9 Trigger module



Software trigger

This is a user-controlled trigger.



The software trigger is activated from the user's application software. It is used for building oscilloscope applications. The software trigger can also be used for a watch-dog application for surveillance of the experiment.



External trigger

This is for synchronizing the acquisition to an experiment.

The external trigger is a signal from another unit that initiates the acquisition. External trigger inputs are available on the front panel and in the backplane in the PXIe and MTCA.4 form factors.



Internal trigger

This is an internally generated signal that can be used for triggering other devices.


The internal trigger generates a programmable periodic signal that can be used for triggering the digitizer as well as external equipment. It allows the ADQ7 to act as the timing master of a large system, eliminating the need for additional timing cards. The internal trigger is available to other equipment via a connector on the front panel.



Level trigger

This is a data driven acquisition.


The level trigger reacts when the analog input goes above or below a programmable level. A more advanced version of the level trigger is available via the -FWPD (pulse detection) option.



Pre-trigger buffer

Capture data before the trigger.

The pre-trigger buffer allows for capturing of data long before the trigger event occurred. This is useful for analyzing the cause of an event.




Trigger delay

Capture data long after the trigger event.

The trigger delay feature inserts a delay from the trigger event until data collection starts. It is used to reduce the amount of captured data when the interesting signal is known to occur a certain amount of time after the trigger event.

10 Clock module



Internal clock

High precision clock for stand-alone operation.


The ADQ7 is clocked by an internal clock source. The clock reference is an internal high quality temperature compensated crystal oscillator.



External clock reference

This is for synchronizing the acquisition to an experiment.


The internal clock generator is locked to an externally provided frequency reference. The frequency reference is provided via a connector on the front panel. The PXIe and MTCA.4 form factors can also receive the clock reference from the backplane.



External clock

When there is an external clock available.


In this mode, the ADQ7 is clocked directly with an external clock. The sampling frequency is twice the external clock frequency in 2-channel mode and four times the external frequency in 1-channel mode.



Clock reference output

This is for synchronizing the acquisition to an experiment.


Using the clock reference output, the ADQ7 can act as the clock reference source for the entire system. The clock reference output can also provide reference clock to another ADQ7 so that they become synchronized. This function together with the trigger generator can eliminate the need for external timing cards.



Jitter cleaner PLL

For optimized performance with an external clock reference.

If an external clock reference of 10 MHz is used, the internal jitter cleaner will optimize performance.




Sample skip¹

For adapting the sample rate to the situation and optimize the amount of data.

The sample skip function can easily adjust the sample rate to limit the amount of data. The ADQ7 can then adapt to changing situations.


1. Sample skip cannot be combined with level trigger nor firmware option –FWPD.

11 Firmware options



Data acquisition firmware (-FWDAQ)

This firmware is always included with the ADQ7. It supports the data acquisition modes triggered streaming and continuous streaming. The trigger modes external, internal, software and level trigger are supported as well as internal and external clock references.




Advanced time-domain firmware (-FWATD)

This firmware option enables time-domain analysis with extremely high dynamic range of synchronized repetitive events.

The -FWATD includes three levels of noise reduction; linear filter for high frequency noise suppression; advanced threshold algorithm for non-linear discrimination of noise; and waveform averaging (WFA) for real-time accumulation of repetitive events. All these methods contribute to improved SNR and enable a dynamic range of up to 100 000 : 1.

The DBS algorithm is used for achieving a stable baseline.




Pulse data (-FWPD)

This firmware is optimized for capturing random pulse events. Each channel is individually event-triggered. Trigger level is a fixed user-defined level. The trigger level can also be a user-defined offset from a filtered baseline level to track baseline variations. The record length is dynamic to efficiently accommodate random event lengths. This dynamic record length is data compression through zero suppression which saves disk space.

The DRAM of 4 GByte is used as a data FIFO to buffer bursts of events before transferring data to the host PC.

The DBS algorithm is used for achieving a stable baseline.




Software defined radio (-FWSDR)

This firmware implements software defined radio functions. It includes digital down conversion and decimation. After decimation, the data rate is suitable for streaming to the host PC.

The ADX algorithm guarantees high dynamic performance in the interleaved architecture.

12 Feature enhancement options




Building real-time custom signal processing firmware through the ADQ7 Development Kit

The ADQ7 is equipped with a powerful FPGA which is partly available for customized real-time applications.

SP Devices' ADQ7 Development Kit is an optional FPGA design project that enables custom real-time signal processing of streaming data. More details about this product can be found in the datasheet for the ADQ Development Kit.

The ADQ7 Development Kit is available for firmware options –FWDAQ and –FWPD. The ADQ7 Development Kit is purchased separately.




Large distance synchronization using White Rabbit

The ADQ7 is prepared for large scale timing synchronization using the White Rabbit scheme.

The ADQ7 can receive timing information from a White Rabbit network and adjust time-stamp and clock reference to the global system timing. Trigger information is received and generated to communicate with other parts of the system.

White Rabbit timing is available as standard in the –USB and –MTCA form factors and require a 1 GbE network with White Rabbit support.



General purpose I/O signals

In the standard ADQ7, the external trigger and sync signals can be used as general purpose I/O signals (GPIO).

The ADQ7 can also be extended with a GPIO card with up to 16 single-ended or 8 LVDS signals.¹

1. Contact an SP Devices sales representative for more information.

13 Form factors and data interfaces

Freestanding box (-USB)



ADQ7DC-USB

With the -USB option, the ADQ7 comes in a metal enclosure with mounting flanges. The data and control interface to the host PC is either via USB 3.0 or Ethernet. Two SFP/SFP+ ports are available and one is intended for 10 GbE while the other is intended for White Rabbit time synchronization over 1 GbE. SFP/SFP+ modules are not included. The device is powered by an external desktop power supply.

The software driver automatically detects which data/control interfaces that are connected. It is not recommended to send commands and transfer data over more than one interface.

USB 3.0 flexible interface

- Freestanding operation
- Any PC can be used as the host, including laptops.
- The digitizer can be placed close to the detector.

The SuperSpeed USB 3.0 interface enables freestanding operation so that the ADQ7 can be physically located close to the detector rather than inside the host PC. The cable between the detector and the digitizer can thereby be kept very short for optimal signal quality.

The USB type B connector is equipped with screw posts for securing the USB cable. Cables compliant with the AIA USB3 Vision standard can be used.

With the USB3.0 interface, the digitizer is easily interfaced to any PC. The combination of a sustained data rate of up to 200 MBytes/s, on-board signal processing and the ease-of-use of the USB 3.0 interface enables a flexible and efficient system solution.

10 GbE optical fiber connection

- Electrical isolation for noise immunity.
- The digitizer can be placed close to the detector.
- Allows large physical separation between the digitizer and the host PC.

The 10 GbE interface offers similar advantages as the USB 3.0 interface and additionally, the data transfer capacity is higher (1 GByte/s sustained), the distance to the host can be much longer and there is electrical isolation from the host. The protocol used is UDP. A point-to-point connection to the host is required.


Note that the SFP+ module is not included.

1 GbE interface for White Rabbit

- Large distance precision time distribution

The 1 GbE is intended for White Rabbit timing system. One SFP+ cage can be equipped with optical or electrical modules for 1GbE (not included).

Note that the SFP module is not included.



TYPICAL

ADQ14DC-4C-VG-PXIE

Modular instrumentation with cPCIe / PXIe (-PXIE)

- Modular instrumentation

The cPCIe / PXIe form factor is intended for integration into a chassis for modular instrumentation or large scale acquisition. The ADQ7 can operate in Compact PCI Express or PXI Express chassis. Using the multi-unit sync function, multi-channels systems can be achieved.

ADQ7 support streaming of at least 5 GBytes/s for sending data to disk or additional computational cards over x8 Gen 3 cPCIe / PXIe backplanes.

In a PXI Express chassis, the clock reference from the backplane can be used as clock reference for the digitizer. Backplane trigger is also supported to simplify integration.

Large scale integration with Micro-TCA.4 (-MTCA)

- Large scale integration
- Robust mechanical solution
- 10 GbE and White Rabbit support

The Micro-TCA.4 form factor is intended for integration into a chassis for modular instrumentation or large scale data acquisition. Chassis trigger and clock reference are supported for easy integration.

The ADQ7DC-MTCA primarily uses the PCIe Gen3x4 interface in the backplane for control and data transfer. The -MTCA form factor also includes the 10GbE, USB 3.0 and 1GbE interfaces.



ADQ7DC-MTCA

Systems integration with PCIe interface (-PCIE)

- All in one box
- High performance computing
- Cost effective hardware


The PCIe form factor is for integration into the host PC. The high speed PCIe interface can handle data rates up to 5 GBytes/s over x8 Gen 3 PCIe links. This is especially useful when combining the digitizer with heavy computation in, for example, a GPU in the same PC. The board is half length to enable compact solutions.



TYPICAL

ADQ14DC-2X-PCIE


14 Synchronization support



Clock reference input and output

Sharing clock reference guarantees a common time base.


When outputting the internal clock reference the ADQ7 acts as master. Use the clock reference input when the external equipment supplies the clock reference.



Trigger input and output

The trigger starts the operation simultaneously.

The trigger marks the start of an operation. The ADQ7 can generate a trigger to start external equipment. It can also take a trigger as input to start the acquisition.



Synchronization input and output


Extra trigger to mark beginning of a sequence.

The sync pin can be used as an input for resetting the time-stamp counter. It can also be used as an output for broadcasting an arm command to several ADQ7 units.

Time-stamp

A real-time value for each trigger.


The time-stamp is a real-time value for each trigger event. The time-stamp allows precise analysis of the timing relationship of different acquisitions from the same or different ADQ7 units.



Sub-sample precision time-stamp

High precision external trigger.

The external trigger timing precision is four times higher than the sampling time period for precise timing analysis. The subsample precision of the time-stamp also allows for automatic analysis of trigger signal timing.



Bussed connection

Save cabling by bussed connections.

The sync, trig and clock reference can be set in high impedance mode to enable bussed connections. For best signal integrity, SMA tee adapters should be used at the high-impedance inputs to minimize the length of the unterminated stubs.




White Rabbit time distribution

Building a system covering several kilometers of distance.

Using a White Rabbit Ethernet-based time distribution network allows the sampling clock and time-stamp of ADQ7 to be locked to a central clock with sub-nanosecond precision over a distance of several km. See [Section 12](#) for more details.


15 Built-in signal processing



Gain and offset calibration

Digital signal tuning in the FPGA.


The user can set gain and offset parameters that are applied to the digitized signal immediately after the analog-to-digital converters. This can e.g. be useful to compensate for system offsets and simplify later signal processing in the host computer.



Level trigger

Data driven acquisition.


The standard firmware contains a level trigger for data driven acquisition. The firmware option –FWPD contains more advanced pulse detection and analysis functionality. The –FWPD also contains zero-suppression to reduce the amount of data.



DBS – Digital baseline stabilizer

Enable accurate pulse detection


SP Devices' proprietary technology for baseline stabilization, DBS, tracks and compensates for baseline variations to suppress, for example, temperature drift in the detector. This enables accurate triggering even on small pulses and eliminates interleaving pattern noise, which can be particularly important when averaging many acquisitions. The precision of DBS is as high as 22 bits.



ADX interleaving technology

Maximize spectral purity over a large bandwidth.


SP Devices' proprietary interleaving technology ADX is available in the firmware option –FWSDR. ADX dynamically suppresses interleaving artifacts to produce a pure spectrum.



Waveform averaging

Data reduction in scheduled repeated measurements.


The firmware option -FWATD offers advanced averaging of waveforms to bring out the signal from the noise when acquiring repeating waveforms.



DDC for SDR

Quadrature Mixer and decimation.

The firmware option -FWSDR is a flexible software defined radio firmware that can operate in several different modes such as an IQ IF receiver or as a dual multi-channel receiver. The firmware incorporates numerically controlled oscillators, quadrature mixers and decimation blocks to extract the channels of interest.



Custom real-time processing

Efficient real-time algorithm implementation.

The ADQ7 Development Kit opens the FPGA for custom implementation of real-time algorithms. See [Section 12](#) for more information.

16 Appendix

16.1 Connectors

All connectors have some form of locking function to prevent cables from accidentally coming loose.

FUNCTION	CONNECTOR	PLACED	-USB	-PXIE	-MTCA	-PCIE	LOCK FUNCTION
Analog	SMA	Front panel	✓	✓	✓	✓	Screw
Trigger I/O	SMA	Front panel	✓	✓	✓	✓	Screw
Clock ref I/O	SMA	Front panel	✓	✓	✓	✓	Screw
Sync I/O	SMA	Front panel	✓	✓	✓		Screw
Sync in	MCX	Internal				✓	Snap lock
Sync out	MCX	Internal				✓	Snap lock
Power	RM12BRD-5PH	Front panel	✓				Bayonet lock
Power	Board edge	Backplane		✓	✓		Board attachment
Aux Power, Section 16.9	PCIe Aux	Internal				✓	Snap lock
GPIO	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Data/control over USB3.0	Type A	Front panel	✓		✓		Friction or screw ¹
Data/control over 10 GbE	SFP+ cage	Front panel	✓		✓		Snap lock
White Rabbit over 1 GbE	SFP+ cage	Front panel	✓		✓		Snap lock
Data/control over PCIe	Board edge	Internal		✓	✓	✓	Board attachment

1. A USB cable with connector according to AIA USB 3.0 Vision standard can be used. This is not included in the standard shipment.

16.2 LED descriptions

COLOR	NAME	LABEL	FUNCTION	STATE
Green	Power	PWR	Power on	On: Power on and FPGA is operating.
Yellow	Ready	RDY	Waiting for trigger	The ADQ7 is waiting for a trigger to occur.
Red	Status	STAT	Overheat	Flashing means overheating or fan fault.
Blue	User	USR	User, Init	On: Initialization from the API in progress. Off: Before or after initialization. This LED can be controlled from the ADQ7 Development Kit.

16.3 Box dimensions




Figure 4: Box drawing for –USB interface options.

The outer dimensions of the –USB version of ADQ7 are shown in [Figure 4](#). The box is designed to be attached with up to six screws. Be careful not to damage the SMA connectors if using the middle screw position on the front side.

The airflow is from left side to right side and all cables are attached in the front panel. This leaves the top, bottom and rear side free to allow for flexible placement.

16.4 Host interface USB 3.0 (option –USB or –MTCA)

See [Section 16.3](#) for box drawing.

The supplied USB cable is a type-A to type-B SuperSpeed. If a more mechanically secure attachment of the cable to the box is desired, a type-A to type-B cable according to the AIA USB 3.0 Vision standard can be used.

16.5 Host interface 10GbE (option –USB or –MTCA)

The ADQ7–USB is equipped with two SFP+ cages that accept SFP / SFP+ modules. The interface is tested with these modules:

- Avago AFBR-709SMZ
- Intel SFP+ E10GSFPSR

Correct operation can only be guaranteed with these modules. The modules are not included.

The cage marked **SFP+1** is the primary cage for 10GbE connection.

The cage marked **SFP+2 WR** is intended for White Rabbit 1GbE timing solution.

16.6 Host interface 1GbE (option –USB or –MTCA)

The SFP/SFP+ cage marked "SFP+2 WR" on ADQ7DC-USB and ADQ7DC-MTCA accepts an SFP module for 1 GbE. This interface is primarily intended for interfacing to a White Rabbit time distribution network.

Note that White Rabbit support is available when using any of the data interfaces Micro-TCA.4, USB 3.0 and 10GbE

16.7 Host interface –PXIE

No additional information available.

16.8 Host interface –MTCA

Micro-TCA backplane connectors are specified in [Table 14](#).

Table 14: MTCA.4 backplane connector use in ADQ7DC–MTCA.



PORT	FUNCTION	SIGNALING	ADQ7DC–MTCA AVAILABILITY
0, 1	1 GbE	–	–
2, 3	SAS/SATA	–	–
4, 5, 6, 7	PCIe	PCIe Gen3 x4	Main data and control interface
8, 9, 10, 11	SRIO	–	–
12, 13, 14, 15	P-t-P	High speed serial	Available through ADQ7 Development Kit only
16	TCLKC/D	–	–
17	Tr/clock/int	MLVDS	Backplane trigger.
18, 19, 20	Tr/clock/int	MLVDS	Available through ADQ7 Development Kit only
Clk 1	TCLKA	LVPECL	Clock reference, select from API
Clk 2	TCLKB	LVPECL	Clock reference, select from API
Clk 3	FCLKA	PCIe clock	PCIe interface reference clock

Available through the ADQ7 Development Kit only means that the physical connection is on the board, but there is no function defined for the signal. The signals are available for inclusion in custom firmware in the FPGA. The custom firmware is designed using the ADQ7 Development Kit.

16.9 Host interface –PCIE

The ADQ7–PCIE is powered from the power supply of the PC via a PCI Express 6-pin (2x3) auxiliary 75W power supply connector, **Figure 6**. The connection in the cable should be as in **Figure 5 (a)**. Some power supplies do not have this connector and an adapter as in **Figure 5 (b)** is required.

It is important that the auxiliary power supply is turned on immediately when the PC start. Otherwise, the digitizer will not be recognized on the PCI Express bus.



(a) Cable connection

(b) Cable adapter example

Figure 5: Power supply of –PCIE




Figure 6: ADQ14 installed in a PC. ADQ7 has the same power supply.

Ordering information

ORDERING INFORMATION	
ADQ7 AC-coupled	ADQ7AC
ADQ7 DC-coupled	ADQ7DC
AVAILABLE OPTIONS	
Host PC interface	-USB, -PCIE, -MTCA, -PXIE,
Firmware options	-FWDAQ, -FWATD, -FWPD, -FWSDR
RELATED PRODUCTS	
ADQ7 Development Kit for FWDAQ	-DEV7DAQ
ADQ7 Development Kit for FWPD	-DEV7PD
AIA USB3 Vision cable with screw lock	108-002-006

References

- 16-1787 ADQ7 presentation
- 16-1794 ADQ7-FWATD datasheet
- 16-1793 ADQ7-FWPD datasheet
- 16-1795 ADQ7-FWSDR datasheet



Important Information

Signal Processing Devices Sweden AB (SP Devices) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to SP Devices' general terms and conditions supplied at the time of order acknowledgment.

SP Devices warrants that each product will be free of defects in materials and workmanship, and conform to specifications set forth in published data sheets, for a period of one (1) year. The warranty commences on the date the product is shipped by SP Devices. SP Devices' sole liability and responsibility under this warranty is to repair or replace any product which is returned to it by Buyer and which SP Devices determines does not conform to the warranty. Product returned to SP Devices for warranty service will be shipped to SP Devices at Buyer's expense and will be returned to Buyer at SP Devices' expense. SP Devices will have no obligation under this warranty for any products which (i) has been improperly installed; (ii) has been used other than as recommended in SP Devices' installation or operation instructions or specifications; or (iii) has been repaired, altered or modified by entities other than SP Devices. The warranty of replacement products shall terminate with the warranty of the product. Buyer shall not return any products for any reason without the prior written authorization of SP Devices.

In no event shall SP Devices be liable for any damages arising out of or related to this document or the information contained in it.

SP DEVICES' EXPRESS WARRANTY TO BUYER CONSTITUTES SP DEVICES' SOLE LIABILITY AND THE BUYER'S SOLE REMEDY WITH RESPECT TO THE PRODUCTS AND IS IN LIEU OF ALL OTHER WARRANTIES, LIABILITIES AND REMEDIES. EXCEPT AS THUS PROVIDED, SP DEVICES DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT.

SP DEVICES DOES NOT INDEMNIFY, NOR HOLD THE BUYER HARMLESS, AGAINST ANY LIABILITIES, LOSSES, DAMAGES AND EXPENSES (INCLUDING ATTORNEY'S FEES) RELATING TO ANY CLAIMS WHATSOEVER. IN NO EVENT SHALL SP DEVICES BE LIABLE FOR SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING LOST PROFIT, LOST DATA AND THE LIKE, DUE TO ANY CAUSE WHATSOEVER. NO SUIT OR ACTION SHALL BE BROUGHT AGAINST SP DEVICES MORE THAN ONE YEAR AFTER THE RELATED CAUSE OF ACTION HAS ACCRUED. IN NO EVENT SHALL THE ACCRUED TOTAL LIABILITY OF SP DEVICES FROM ANY LAWSUIT, CLAIM, WARRANTY OR INDEMNITY EXCEED THE AGGREGATE SUM PAID TO SP BY BUYER UNDER THE ORDER THAT GIVES RISE TO SUCH LAWSUIT, CLAIM, WARRANTY OR INDEMNITY.

Worldwide Sales and Technical Support

www.spdevices.com

SP Devices Corporate Headquarters

Teknikringen 6
SE-583 30 Linköping
Sweden

Phone: +46 (0)13 465 0600
Fax: +46 (0)13 991 3044
Email: info@spdevices.com

Copyright © 2017 Signal Processing Devices Sweden AB.

All rights reserved, including those to reproduce this publication or parts thereof in any form without permission in writing from SP Devices.